

Section 9 WIRING STANDARDS (20.2(4) 1)

9.1 Cooperative's Requirements

9.11 Wiring Specifications

The Cooperative requires compliance with specifications set forth in the National Electrical Safety Code when a member-consumer or other responsible party wires or rewires buildings, premises, etc.

9.12 Inspections

Normally the Cooperative inspects only the service entrance and meter location, but the Cooperative reserves the privilege, for protection of its facilities and safeguarding its service to others, to inspect the applicant's installation at any time and to refuse service whenever such installation, in its opinion fails to meet minimum safety and operating standards. No inspection by the Cooperative, nor failure to object to the member-consumer's installation, shall render the Cooperative liable for injury or damage resulting from any defective installation of member-consumer.

When a government agency requires permits for or an inspection of new installations, the Cooperative will not make service connections until such permit is obtained and the installation passes the required inspection.

9.2 Member-Consumer's Responsibility

9.21 Liability of Member-Consumer

When the wiring of a member-consumer is found to be dangerous, the Cooperative shall require immediate repair. Failure to meet the requirements is cause for disconnection without further notice.